

READ BEFORE USE

Visit www.hamiltonbeach.com.au for our complete line of products and Use and Care Guides – as well as delicious recipes and tips.

Hamilton Beach®

Breakfast Sandwich Maker



IMPORTANT SAFEGUARDS

This product is intended for household use only.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions.
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with the appliance.
4. Do not touch hot surfaces. Use handles or knobs.
5. To protect against risk of electrical shock, do not immerse cord, plug, or cooking unit in water or other liquid.
6. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning.
7. Do not operate any appliance with a damaged supply cord, or after the appliance malfunctions or has been dropped or damaged in any manner. Supply cord replacement and repairs must be conducted by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
8. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
9. Do not use outdoors.
10. Do not let cord hang over edge of table or counter or touch hot surfaces, including the stove.
11. Do not place on or near a hot gas or electric burner, or in a heated oven.
12. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
13. Do not use appliance for other than intended use.
14. Do not use appliance unattended.
15. During use, provide 10 to 15 cm air space above, behind, and on both sides for air circulation.
16. Never remove the food with any kind of cutting device or other metallic kitchen utensil.
17. Always allow the appliance to cool before putting it away, and never wrap the cord around the appliance while it is still hot.
18. **CAUTION:** In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
19. The temperature of accessible surfaces may be high when the appliance is operating.

SAVE THESE INSTRUCTIONS!

Other Consumer Safety Information



The length of the cord used on this appliance was selected to reduce the hazards of becoming tangled in or tripping over a longer cord. If a longer cord is necessary, an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the appliance. Care must be taken

to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

To avoid an electrical circuit overload, do not use another high-wattage appliance on the same circuit with this appliance.

Parts and Features


BEFORE FIRST USE: Lift cover to remove ring assembly. Wash removable ring assembly in dishwasher or in hot, soapy water. Rinse and dry. Wipe top and bottom heating plates with a damp, soapy cloth. Remove soap with a damp cloth; dry thoroughly. Spray rings with nonstick cooking spray or wipe or brush with vegetable oil.




How to Use

WARNING Burn Hazard.

Always use an oven mitt to protect hand when opening cover. Hot surfaces and escaping steam can burn.




1 Plug cord into wall outlet. The red **POWER** light will glow. Lightly spray rings with nonstick cooking spray before each use.




2 Let unit preheat with cover closed and cooking plate rotated in between rings.

NOTE: Green **PREHEAT** light will come on when unit is heated to the correct temperature and will cycle on and off during cooking. It is **NOT** an indicator when sandwich is ready. Red **POWER** light stays on.



3 Use handles to lift cover, top ring, and cooking plate.




4 Place bottom half of bread (such as an English muffin, small bagel, or biscuit) onto bottom plate.



5 Top bread with ingredients such as precooked meats, vegetables, and cheese. Do not overfill breakfast sandwich maker. Overfilling will cause food to spill over rings and get stuck in the hinges.



6 Move top ring and cooking plate down. Make sure cooking plate is rotated securely to back of ring as far as it will go to prevent leaking of egg.



7 Crack an egg onto cooking plate. Pierce yolk with a fork or toothpick. (You can use a whole large egg, egg white, or a scrambled egg.)


How to Use (cont.)




8 Top with the other half of bread.




9 Close cover. Cook sandwich for 4 to 5 minutes. **NOTE:** Do not push lid all the way down when loaded with ingredients or when using a jumbo egg. Lid may rise as scrambled egg cooks.



10 When finished cooking, rotate cooking plate handle clockwise until it stops.




11 Using an oven mitt, lift ring assembly and cover by holding bottom handle to open. Some sandwiches are easier to remove if rings are lifted individually.



12 Remove breakfast sandwich with plastic or wooden utensil. Never use metal.

Always wait 2 minutes between cooking sandwiches to ensure the breakfast sandwich maker is heated to the correct temperature.



13 Unplug when through cooking. Let cool.

TIPS:


- Get your ingredients together before cooking your sandwich.
- Always keep cover closed with rings and cooking plate in place when preheating.
- Check to make sure the cooking plate is in place before preheating and when adding food.

Care and Cleaning

WARNING


Electrical Shock Hazard.

Disconnect power before cleaning. Do not immerse cord, plug, or base in any liquid.




1

Unplug unit when through cooking. Let cool.



2

To remove ring assembly for cleaning, hold bottom handle to open, and then lift straight up.



3

Removable Ring Assembly

Do not use steel wool, scouring pads, or abrasive cleansers on any part of the unit. Never use sharp or pointed objects for cleaning.




**TOP-RACK
DISHWASHER-SAFE**

DO NOT use the "SANI" setting when washing in the dishwasher. "SANI" cycle temperatures could damage your product.




4

Wipe top and bottom heating plates with a damp, soapy cloth. Remove soap with a damp cloth; dry thoroughly.



5

To replace ring assembly, align tabs on the ring assembly with the openings on the hinge of the base, and lower.



6

Wipe outside of unit with a damp, soapy cloth.

Troubleshooting

PROBLEM	PROBABLE CAUSE/SOLUTION
Low, poor, or slow heating.	<ul style="list-style-type: none"> • Breakfast sandwich maker wasn't preheated until PREHEAT light was illuminated. Green PREHEAT light will come on in about 5 to 7 minutes indicating unit is heated to the correct temperature. Light will cycle and does not indicate sandwich is ready. • Allow 2 minutes between making sandwiches for breakfast sandwich maker to heat to the correct temperature. • Overfilled. Reduce amount of ingredients in your sandwich. • Unit needs to be preheated with the cover closed with rings and cooking plate in place. • Make sure cooking plate is rotated securely to back of ring as far as it will go, to prevent leaking of egg, and cover is closed when preheating.
Egg undercooked, bread not done.	<ul style="list-style-type: none"> • Extra large eggs, frozen, or very cold ingredients may lengthen cooking time. Add additional cooking time.
Egg overcooked.	<ul style="list-style-type: none"> • Cooking time is about 5 minutes. Cooking time may vary if you are using small eggs, scrambled or egg whites. Reduce cooking time for future recipes.
Ingredients stick to rings or nonstick cooking plate.	<ul style="list-style-type: none"> • Use a plastic or wooden utensil to loosen any baked-on ingredients. Lightly spray with nonstick cooking spray before preheating for next use.
Eggs leak out of rings.	<ul style="list-style-type: none"> • Unit is overfilled. Only use large eggs and reduce amount or size of ingredients. Do not press down on the cover. • Cooking plate may not have been in the correct position. Make sure cooking plate is rotated securely to back of ring as far as it will go to prevent leaking of egg. • Used very thin purchased egg whites. Use fresh egg white or try a different brand of egg whites.
Cover rises when cooking my sandwich.	<ul style="list-style-type: none"> • The air whisked into a large scrambled egg may cause the cover to rise while the egg is cooking. Do not press down on the cover.
Bread too brown.	<ul style="list-style-type: none"> • Higher fat contents and sugars may cause breads too darken. Cook egg for several minutes without bread and cover down. Then add bread to finish cooking your sandwich.

Recipes

Egg, Ham, and Cheese Breakfast Sandwich

- 1 English muffin, split
- 1 slice cheese
- 1 slice precooked bacon or ham
- 1 large egg

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Lift cover, top ring, and cooking plate.
2. Place half of muffin, split-side up, in bottom ring of Breakfast Sandwich Maker. Top with cheese and bacon.
3. Lower cooking plate and top ring. Add egg to cooking plate. Pierce yolk with a fork or toothpick.
4. Top with remaining muffin half, split-side down.
5. Close cover. Cook 4 to 5 minutes. Rotate cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula.

Serves: 1

Piklets and Sausage Sandwich

- 2 (10 cm) piklets
- 1 precooked thin sausage patty
- 1 large egg
- Maple syrup

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Lift cover, top ring, and cooking plate.
2. Place one frozen piklet in bottom ring of Breakfast Sandwich Maker. Top with sausage.
3. Lower cooking plate and top ring. Add egg to cooking plate. Pierce yolk with a fork or toothpick.
4. Top with remaining piklet.
5. Close cover. Cook 4 to 5 minutes. Rotate cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula. Serve with syrup.

Serves: 1

Recipes (cont.)

Cheddar, Apple, Bacon, and Egg Croissant Sandwich

- 1 small croissant, halved
- 2 Tablespoons (40 ml) shredded Cheddar cheese
- 4 thin slices Granny Smith apple
- 1 slice precooked bacon, cut in half
- 1 large egg

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Lift cover, top ring, and cooking plate.
2. Place half of croissant, cut-side up, in bottom ring of Breakfast Sandwich Maker. Top with cheese, apple slices, and bacon.
3. Lower cooking plate and top ring. Add egg to cooking plate. Pierce yolk with a fork or toothpick.
4. Top with remaining croissant half, cut-side down.
5. Close cover. Cook 4 to 5 minutes. Rotate cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula.

Serves: 1

Southwestern Breakfast Muffin

- 1 whole wheat English muffin, split
- 1 slice Monterey Jack cheese
- 3 thin slices avocado
- 1 large egg white
- 1 Tablespoon (20 ml) salsa

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Lift cover, top ring, and cooking plate.
2. Place half of muffin, split-side up, in bottom ring of Breakfast Sandwich Maker. Top with cheese and avocado.
3. Lower cooking plate and top ring. Add egg white to cooking plate.
4. Top with remaining muffin half, split-side down.
5. Close cover. Cook 4 to 5 minutes. Rotate cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula. Serve with salsa.

Serves: 1

Recipes (cont.)

Cheesy Egg and Sausage Bagel

- 1 small bagel, halved
- 1 slice Jarlsberg cheese
- 1 precooked thin sausage patty
- 1 thin slice red pepper ring
- 1 large egg

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Lift cover, top ring, and cooking plate.
2. Place half of bagel, split-side up, in bottom ring of Breakfast Sandwich Maker. Top with cheese, sausage, and red pepper ring.
3. Lower cooking plate and top ring. Add egg to cooking plate. Pierce yolk with a fork or toothpick.
4. Top with remaining bagel half, split-side down.
5. Close cover. Cook 4 to 5 minutes. Rotate cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula.

Serves: 1

Herb Goat Cheese, Spinach, and Tomato Egg Muffin

- 1 whole wheat English muffin, split
- 1 Tablespoon (20 ml) herb goat cheese
- 1 thin slice tomato
- 4 spinach leaves
- 1 thin slice red pepper ring
- 1 large egg white

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Spread goat cheese over bottom half of muffin. Lift cover, top ring, and cooking plate.
2. Place half of muffin, goat cheese side up, in bottom of Breakfast Sandwich Maker. Top with tomato, spinach, and red pepper ring.
3. Lower cooking plate and top ring. Add egg white to cooking plate.
4. Top with remaining muffin half, split-side down.
5. Close cover. Cook 4 to 5 minutes. Move cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula.

Serves: 1

Notes

Warranty

The product you have purchased is covered by a warranty in the terms below. This warranty is provided by Toymonster International Limited ("we", "Toymonster"). The warranty applies for a period of 12 months from the date of your purchase.

Toymonster warrants that the product will be substantially free from defects for the warranty period. To the extent permitted at law, and subject to the following paragraph, Toymonster will, at its election, repair, replace, or provide credit in respect of goods that are defective in the warranty period.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a "major failure" and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.

The term "major failure" is defined in the Australian Consumer Law and includes but is not limited to:

- where the goods are substantially unfit for the purpose for which such goods are commonly supplied and cannot easily and within a reasonable time be remedied to make them fit for such a purpose; or
- where the goods are unsafe.

The benefits provided by this warranty are in addition to any other rights and remedies of the consumer under any law in relation to the goods or services to which the warranty relates.

Exclusions

The warrant does not cover defects or problems that arise due to you causing the product to become of unacceptable quality, such as failure to take reasonable care of the product or damage caused by abnormal use of the product. To the extent permissible at law, it does not cover damage caused by dismantling of the product or attempts at repairs by persons other than Toymonster or its authorised repairers, or by your use of the product contrary to any usage recommendations of Toymonster.

Further, the warranty does not cover defects where you were informed of the issue before agreeing to acquire the goods or you examined the goods before accepting them and that examination ought reasonably have revealed the position.

How to claim under the warranty

For the warranty to be honoured, you must submit the faulty product, together with proof of purchase, to the original place of purchase or send them to Warranty Claims, Toymonster International Limited, 5th Floor, No. 16, Lane 658, Jin Zhong Rd., Chang Ning District, Shanghai, PRC 200335. For telephone enquiries, contact 86-21-62385522. For email enquiries, contact: cs@toymonster.net.

You must bear the costs associated with making the warranty claim (such as the sending in of the product and proof of purchase).

We will assess the defect and, as long as none of the exclusions above apply, will repair, replace, provide a credit or refund for the product in accordance with the above. If applicable we will return the repaired or replaced product to you by the channel through which it was submitted to us.